

FENCE CANADA www.wholesalefence.ca

Step 1: Put the aluminium post into the gound and fix it with cement.





